USER MANUAL

OLIGHT

IN THE BOX

Above data are tested per IAEC/PLETC-1 (2011) standard or Olight's data for reference only. Actual results may vary due to factors such as battery condition, ambient temperature, etc. Find more information regarding of the exterior temperature and ventilation conditions, and these factors may affect the results of testing.

Table 2:

Wireless Charger

Main Body	Plastics
Dimensions	92*32*8 mm / 2.56*1.26*0.31 in
Weight	142 g / 5.01 oz
Battery Capacity	5000 mAh 3.6 V (18 Wh)
Rated Capacity	2050 mAh (7.2 V) / 2.4 A)
TYPE-C Input	5 V 2.0 A (Recommended for adaptor)
TYPE-C Output	5 V 2.4 A (MAX)
Charger-to-Flashlight Output	4.2 V 1 A
Time to Charge Person 3 Mini	1.5 hours

USB-C Charging Cable

Charge Type	USB-C
Cable length	0.8 m
Input	5 V / 2 A
Time to Charge the Wireless Charger	5 hours (Charging a 5V 2A USB power source. When the power source capacity is insufficient, the charging time is correspondingly longer.)

Figure 1
Product Overview



Figure 2
Remove the insulating film before use

Figure 3
Charge the Wireless Charger

Figure 4
Charge the flashlight with the charger



Figure 5
Charge external devices with the charger



Figure 6
Lockout mode



Figure 7
Turbo



Figure 8
Moonlight



Figure 10
Change Brightness Level



Figure 11
Auto Shut-Off function

Figure 12
Turn On the Flashlight

Figure 13
Charge Lighting Mode



Figure 14
Turn Off the Flashlight



Figure 15
Battery Indicator



Figure 16
Battery Indicator (Moonlight Mode)

Figure 17
Attach the Flashlight to the Headband

Figure 18
Wireless charger operation instructions
Turn the flashlight ON/OFF with the charger

Figure 19
Close the tail to turn off the light

Figure 20
Moonlight mode

Figure 21
Charge the flashlight brightness with the charger

Figure 22
Low battery indication

Perun 3 Mini operation instructions
INSTRUCTIONS FOR WHITE LIGHT MODE
Figure 6
Turn On/Off the Flashlight

INSTRUCTIONS FOR RED LIGHT MODE
Figure 12
Turn On the Flashlight



Figure 13
Charge Lighting Mode



Figure 14
Turn Off the Flashlight

Figure 15
Battery Indicator



Figure 16
Battery Indicator (Moonlight Mode)



Figure 17
Turbo



Figure 18
Moonlight



Figure 19
Brightness Level



Figure 20
Auto Shut-Off function

Figure 21
Lockout mode

Figure 22
Moonlight



CONTENTS

(EN) English 01
(CH) 简体中文 02
(FI) Finnish 03
(NO) Norwegian 04
(SV) Swedish 05
(NL) Nederlands 06
(PL) Polska 07
(DE) Deutsch 08
(HU) Magyarország 09
(RU) Русский 10
(ES) Español 11
(RO) Romanesc 12
(UA) Українська 13
(JP) 日本語 14
(KR) 한국어 15
(TH) ไทย 16
(FR) Français 17
(IT) Italiano 18
(SK) Slovenskjazyk 19
(PT) Português 20

(EN) English

NOTE TO OPTICIAN

1. **Product specifications, see Table 1 and Table 2**
2. **Product overview, see Figure 1**
3. **Product instructions as below**

Figure 2 Remove the insulating film before first use, see Figure 2

Figure 3 Wireless charger operation instructions for charger, see Figure 18

Place the Wireless Charger on a flat surface. Connect the charging cable to the charging port, and plug the other end into a power source. The magnetic Moonlight Cleaning Cloth, Moonlight cable, and headband can be stored in the charger. Charge the flashlight with the charger, see Figure 4.

Figure 4 Charge the flashlight with the charger

Place the flashlight onto the charging port. The magnetic charging port will automatically adsorb the flashlight and align it with the charging port. The flashlight will be charged with the charging port. Charging time is approximately 1.5 hours. The charging port will automatically stop charging when the battery is full.

Figure 5 Charge external devices with the charger

Connect the charging cable to the charging port, and plug the other end into the charging port of the charger. The charger can be used to charge other devices, such as mobile phones, headlamps, headlamps, headlamps